



APPLICATION NOTES:

- 1) ENSURE ADHESIVE SIDE OF PRE-TAK MEMBRANE IS FACING TOWARDS THE CONCRETE POUR.
- 2) DO NOT TAPE FOLD ONTO VERTICAL SURFACE.

KINGFIELD CONSTRUCTION PRODUCTS 20 N 4th St, Suite 300 Minneapolis, MN 55401 e: info@kingfieldcp.com o/f: 612.225.5167	INSIDE CORNER & TOP OF WALL CORNER DETAIL	DETAIL # PRE-003B
		SYSTEM: PRE-TAK
		ISSUED: 12/15/2017
		SCALE: No To Scale