



NOTES:

- 1) PRE-TAK MEMBRANE BOOT MUST FIT SNUG AROUND CONDUIT / PIPE WITHOUT FOLDING OR FALLING DOWN. PRE-TAK TAPE MUST BE USED TO COMPLETELY SEAL BETWEEN BOOT AND PIPE. TIGHTEN HOSE CLAMPS AS TIGHT AS POSSIBLE WITHOUT DAMAGING THE MEMBRANE.
- 2) SPACE PENETRATIONS A MINIMUM OF 6" AWAY FROM SLAB, CORNERS, WALLS, OR OTHER PENETRATIONS
- 3) SEPA SEAL SH-100: 1/4" BEAD = MIN. 2" CONCRETE COVER - 1/2" BEAD = MIN. 4" OF CONCRETE COVER
- 4) BENTOTAK AB: MIN. 2" CONCRETE COVER

<p>KINGFIELD CONSTRUCTION PRODUCTS 20 N 4th St, Suite 300 Minneapolis, MN 55401 e: info@kingfieldcp.com o/f: 612.225.5167</p>	<p>PRE-TAK DETAIL: Horizontal Pipe Penetration - Field Manufactured Pipe Collar</p>	DETAIL # PRE-006A
		SYSTEM: PRE-TAK
		ISSUED: 09/15/2018
		SCALE: No To Scale