



NOTE: ALL PRE-TAK SEAMS SHOULD BE POSITIONED OVER BACK LAGGING WITH A SEAM LOCATION A MINIMUM 6 INCHES BEYOND EDGE OF FILLER MATERIAL

KINGFIELD
CONSTRUCTION PRODUCTS

20 N 4th St, Suite 300
Minneapolis, MN 55401
e: info@kingfieldcp.com
o/f: 612.225.5167

PRE-TAK DETAIL:
SOLDIER PILE - BACK LAGGING WITH CANTED FLANGE FILLER

DETAIL # PRE-010B

SYSTEM: PRE-TAK

ISSUED: 02/01/2019

SCALE: No To Scale