



NOTE:
REMOVE ANY LOOSE PRE-TAK MATERIAL FROM TOP OF OUTER FOOTING TO ENSURE THE SECURE BOND OF KINGFIELD POST-APPLIED WATERPROOFING MATERIALS

KINGFIELD CONSTRUCTION PRODUCTS 20 N 4th St, Suite 300 Minneapolis, MN 55401 e: info@kingfieldcp.com o/f: 612.225.5167	PRE-TAK DETAILS: WRAPPED FOOTING TRANSITION TO SLAB ON GRADE (TRANSITION TO KINGFIELD POST-APPLIED WATERPROOFING SYSTEMS)	DETAIL # PRE-017
		SYSTEM: PRE-TAK
		ISSUED: 12/15/2017
		SCALE: No To Scale