



NOTES:

- 1) **PRE-TAK MEMBRANE BOOT MUST FIT SNUG AROUND CONDUIT / PIPE WITHOUT FOLDING OR FALLING DOWN. PRE-TAK TAPE MUST BE USED TO COMPLETELY SEAL BETWEEN BOOT AND PIPE. TIGHTEN HOSE CLAMPS AS TIGHT AS POSSIBLE WITHOUT DAMAGING THE MEMBRANE.**
- 2) **SPACE PENETRATIONS A MINIMUM OF 6" AWAY FROM SLAB, CORNERS, WALLS, OR OTHER PENETRATIONS**
- 3) **SEPA SEAL SH-100: 1/4" BEAD = MIN. 2" CONCRETE COVER - 1/2" BEAD = MIN. 4" OF CONCRETE COVER**
- 4) **BENTOTAK AB: MIN. 2" CONCRETE COVER**

<p>KINGFIELD CONSTRUCTION PRODUCTS 20 N 4th St, Suite 300 Minneapolis, MN 55401 e: info@kingfieldcp.com o/f: 612.225.5167</p>	<p>PRE-TAK HEAT-WELD DETAIL: Horizontal Pipe Penetration - Field Manufactured Pipe Collar</p>	<p>DETAIL # PRE-HW-007A</p>
		<p>SYSTEM: PRE-TAK</p>
		<p>ISSUED: 09/15/2018</p>
		<p>SCALE: No To Scale</p>