



NOTES:

- 1) **PRE-TAK MEMBRANE BOOT MUST FIT SNUG AROUND CONDUIT / PIPE WITHOUT FOLDING OR FALLING DOWN. PRE-TAK TAPE MUST BE USED TO COMPLETELY SEAL BETWEEN BOOT AND PIPE. TIGHTEN HOSE CLAMPS AS TIGHT AS POSSIBLE WITHOUT DAMAGING THE MEMBRANE.**
- 2) **SPACE PENETRATIONS A MINIMUM OF 6" AWAY FROM SLAB, CORNERS, WALLS, OR OTHER PENETRATIONS**
- 3) **SEPA SEAL SH-100: 1/4" BEAD = MIN. 2" CONCRETE COVER - 1/2" BEAD = MIN. 4" OF CONCRETE COVER**
- 4) **BENTOTAK AB: MIN. 2" CONCRETE COVER**

KINGFIELD
 CONSTRUCTION PRODUCTS
 20 N 4th St, Suite 300
 Minneapolis, MN 55401
 e: info@kingfieldcp.com
 o/f: 612.225.5167

PRE-TAK HEAT-WELD DETAIL:
 Vertical Pipe Penetration - Field Manufactured Pipe Collar

DETAIL # PRE-HW-007B
 SYSTEM: PRE-TAK
 ISSUED: 09/15/2018
 SCALE: No To Scale